



# Technical Data

## Nexus Grid Rockers

### Brief product description:

The Nexus Grid range is ideal for domestic, commercial and industrial applications, and allows you to build your own module configurations with a variety of combinations and finishes.

### Features:

- Replacement rockers available in all finishes
- Plastic – printed, metal – embossed
- Supplied in packs of 10
- Easy to fit on standard Grid switch modules

### Product Images



RRBELW

RRBLW

RRFZBS

RRHBBS

RRCHPC

RRDWPC

RRFDBN

RRTDBN



RRUPW

RRUPBS

RRUPPC

RRUPBN

RRUPAB

RRUPG

RRUPRD


### Printed / Embossed Rocker options include:

Hob, Oven, Fan, Washing Machine, Tumble Dryer, Fridge, Freezer, Fridge Freezer, Boiler, Microwave, Cooker Hood, Water Heater, Waste Disposal, Air Con, Dish Washer, Bell Symbol

### Unprinted Rocker Options include:

White, Black Nickel, Polished Chrome, Brushed Steel, Part M (Graphite), Red, Antique Brass

### Line Diagrams





# Nexus Grid Rockers

## Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
RRHBW	"HOB" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204781	5050765205535	5050765206280
RROVW	"OVEN" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204798	5050765205542	5050765206297
RRFNW	"FAN" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204804	5050765205559	5050765206303
RRWMW	"WASHING MACHINE" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204811	5050765205566	5050765206310
RRTDW	"TUMBLE DRYER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204828	5050765205573	5050765206327
RRFDW	"FRIDGE" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204835	5050765205580	5050765206334
RRFZW	"FREEZER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204842	5050765205597	5050765206341
RRFFW	"FRIDGE FREEZER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204859	5050765205603	5050765206358
RRBLW	"BOILER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204866	5050765205610	5050765206365
RRMWW	"MICROWAVE" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204873	5050765205627	5050765206372
RRCHW	"COOKER HOOD" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204880	5050765205634	5050765206389
RRHWH	"WATER HEATER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204897	5050765205641	5050765206396
RRWDISW	"WASTE DISPOSAL" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204903	5050765205658	5050765206402
RRACW	"AIR CON" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204910	5050765205665	5050765206419
RRDWW	"DISH WASHER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204927	5050765205672	5050765206426
RRBELLW	BELL SYMBOL - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204934	5050765205689	5050765206433
RRHTW	"HEATER" - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204958	5050765205702	5050765206457
RRUPW	WHITE (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204941	5050765205696	5050765206440
RRHBPC	"HOB" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204989	5050765205733	5050765206488
RROVPC	"OVEN" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204996	5050765205740	5050765206495
RRFNPC	"FAN" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205009	5050765205757	5050765206501
RRWMPC	"WASHING MC" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205016	5050765205764	5050765206518
RRTDPC	"TUMBLE DRYER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205023	5050765205771	5050765206525
RRFDPC	"FRIDGE" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205030	5050765205788	5050765206532
RRFZPC	"FREEZER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205047	5050765205795	5050765206549
RRFFPC	"FRIDGE FREEZER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205054	5050765205801	5050765206556
RRBLPC	"BOILER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205061	5050765205818	5050765206563
RRMWPC	"MICROWAVE" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205078	5050765205825	5050765206570
RRCHPC	"COOKER HOOD" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205085	5050765205832	5050765206587
RRHPC	"WATER HEATER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205092	5050765205849	5050765206594
RRWDISPC	"WASTE DISPOSAL" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205108	5050765205856	5050765206600
RRACPC	"AIR CON" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205115	5050765205863	5050765206617
RRDWPC	"DISH WASHER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205122	5050765205870	5050765206624
RRBELLPC	BELL SYMBOL - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205139	5050765205887	5050765206631
RRHTPC	"HEATER" - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205146	5050765205894	5050765206648
RRUPC	POLISHED CHROME (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205153	5050765205901	5050765206655
RRHBBS	"HOB" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205160	5050765205917	5050765206662
RROVBS	"OVEN" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205177	5050765205924	5050765206679
RRFNBS	"FAN" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205184	5050765205931	5050765206686
RRWMBS	"WASHING MACHINE" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205191	5050765205948	5050765206693
RRTDBS	"TUMBLE DRYER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205207	5050765205955	5050765206709
RRFDBS	"FRIDGE" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205214	5050765205962	5050765206716
RRFZBS	"FREEZER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205221	5050765205979	5050765206723
RRFFBS	"FRIDGE FREEZER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205238	5050765205986	5050765206730
RRBLBS	"BOILER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205245	5050765205993	5050765206747
RRMWBS	"MICROWAVE" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205252	5050765206006	5050765206754
RRCHBS	"COOKER HOOD" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205269	5050765206013	5050765206761
RRHBS	"WATER HEATER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205276	5050765206020	5050765206778
RRWDISBS	"WASTE DISPOSAL" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205283	5050765206037	5050765206785
RRACBS	"AIR CON" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205290	5050765206044	5050765206792
RRDWBS	"DISH WASHER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205306	5050765206051	5050765206808
RRBELLBS	BELL SYMBOL - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205313	5050765206068	5050765206815
RRHTBS	"HEATER" - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205320	5050765206075	5050765206822
RRUPBS	BRUSHED STEEL (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205337	5050765206082	5050765206839



# Nexus Grid Rockers

## Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
RRHBBN	"HOB" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205344	5050765206099	5050765206846
RROVBN	"OVEN" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205351	5050765206105	5050765206853
RRFNBN	"FAN" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205368	5050765206112	5050765206860
RRWMBN	"WASHING MACHINE" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205375	5050765206129	5050765206877
RRTDBN	"TUMBLE DRYER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205382	5050765206136	5050765206884
RRFDBN	"FRIDGE" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205399	5050765206143	5050765206891
RRFZBN	"FREEZER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205405	5050765206150	5050765206907
RRFFBN	"FRIDGE FREEZER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205412	5050765206167	5050765206914
RRBLBN	"BOILER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205429	5050765206174	5050765206921
RRMWBN	"MICROWAVE" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205436	5050765206181	5050765206938
RRCHBN	"COOKER HOOD" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205443	5050765206198	5050765206945
RRWHBN	"WATER HEATER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205450	5050765206204	5050765206952
RRWDISBN	"WASTE DISPOSAL" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205467	5050765206211	5050765206969
RRACBN	"AIR CON" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205474	5050765206228	5050765206976
RRDWBN	"DISH WASHER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205481	5050765206235	5050765206983
RRBELLBN	BELL SYMBOL - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205498	5050765206242	5050765206990
RRHTBN	"HEATER" - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205504	5050765206259	5050765207003
RRUPBN	BLACK NICKEL (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205511	5050765206266	5050765207010
RRUPRD	RED (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204965	5050765205719	5050765206464
RRUPG	GRAPHITE (UNPRINTED) - PART M	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204972	5050765205726	5050765206471
RRUPAB	ANTIQU BRASS (UNPRINTED)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205528	5050765206273	5050765207027

## Weights & Dimensions

Cat No.	Description	Dimensions (H x W x D) cm			Weight (kg)			CBM (m <sup>3</sup> )
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Outer Box
RR**W	White Rocker (All)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.03	0.33	3.47	0.00952
RR**PC	Polished Chrome Rocker (All)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.046	0.49	5.07	0.00952
RR**BS	Brushed Steel Rocker (All)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.048	0.51	5.27	0.00952
RR**BN	Black Nickel Rocker (All)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.048	0.51	5.27	0.00952
RRUPRD	Red Rocker (Unprinted)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.043	0.46	4.77	0.00952
RRUPG	Graphite Rocker (Unprinted)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.043	0.46	4.77	0.00952
RRUPAB	Antique Brass Rocker (Unprinted)	2.7 x 1.4 x 0.7	7 x 9.7 x 11.8	13.1 x 20.3 x 35.8	0.043	0.46	4.77	0.00952